

## Unilux VFC Integrated

- A** Change paper filter every 3 months (Lift hinged lower access panel and slide filter up to remove — Replace with a new Unilux Filter)
- B** Wash foam Filters every 3 months and replace annually
- C** Vacuum core every 3 months
- D** Replace core every 24 months

Visit [uniluxvfdirect.com](http://uniluxvfdirect.com) and click maintenance for instructions — we will also include detailed instructions with any parts purchase.



**Your comfort is  
our business**  
— SINCE 1970 —

Visit [uniluxvfdirect.com](http://uniluxvfdirect.com) to purchase:

- Paper Filters
- Foam Filters
- HRV/ERV Cores

**Parts Hot Line:**  
905.265.2418

**Contact Us:**  
[info@uniluxvfdirect.com](mailto:info@uniluxvfdirect.com)  
Toll Free: 1.800.397.3680  
ph. 905.265.2418  
fx. 905.851.3987

140 Hanlan Road, Unit A  
Woodbridge, ON L4L 3P6

[uniluxvfdirect.com](http://uniluxvfdirect.com)



 MANUFACTURED IN CANADA



**Your suite is equipped with state  
of the art HVAC equipment**



**Please read about the special features of your  
Unilux VFC integrated HVAC system**

## Unilux VFC with Integrated HRV/ERV


Your HVAC Equipment includes an energy recovery ventilator.

For you to enjoy the benefits of your Unilux HVAC some **regular maintenance** is required and you can do it yourself!

Fresh air is brought into your suite and is heated or cooled to recover up to 70% of the energy.

### You Enjoy:

- Lower Energy Costs
- Constant fresh air supply
- Reliable, efficient heating and cooling
- The quietest HVAC System on the market



**D** Visit [uniluxvfdirect.com](http://uniluxvfdirect.com) to purchase replacement cores online or call 905.265.2418

