

Unilux Vertical Fan Coil

- A** Change paper filter every 3 months (Lift hinged lower access panel and slide filter up to remove — Replace with a new Unilux Filter)
- B** Replace old style thermostat with programmable to save money

Visit uniluxvfcdirect.com and click maintenance for instructions — we will also include detailed instructions with any parts purchase.



**Your comfort is
our business**

— SINCE 1970 —

Visit uniluxvfcdirect.com to purchase:

- Paper Filters
- Access Panels
- Ventilation Grilles
- Thermostats

Parts Hot Line:
905.265.2418

Contact Us:
info@uniluxvfcdirect.com
Toll Free: 1.800.397.3680
ph. 905.265.2418
fx. 905.851.3987

140 Hanlan Road, Unit A
Woodbridge, ON L4L 3P6

uniluxvfcdirect.com



MANUFACTURED IN CANADA



**Your suite is equipped with
Unilux VFC HVAC equipment**



**Please read about how to maintain
your Unilux VFC HVAC system**

Unilux Vertical Fan Coil

Step 1

To remove the filter open the front access panel door and pull the door towards you, as shown here.



Step 2

Turn off the electrical power source at top right of the unit. Allow the rotating fan wheel to stop.



Step 3

Slide filter up and replace with genuine Unilux filter.



Clean Filter = Clean Air

For you to enjoy the benefits of your Unilux HVAC some **regular maintenance** is required and you can do it yourself!



APARTMENTS

| CONDOS

| ASSISTED LIVING

| HOTELS

| RESORTS